



CD Automation UK Ltd

Product Support:

Tel: +44 1323 811100 Email: info@cdautomation.co.uk



Declaration of conformity

Declaration of conformity - Dichiarazione di Conformità

PRODUCT MANUFACTURER / PRODUTTORE:



CD Automation S.R.L.

Controllers, Drives & Automation

Via Picasso, 34/36 - 20025 Legnano (MI)- Italy

P.I. 08925720156 -Tel. +39 0331 577479 - Fax +39 0331 579479

E-mail: info@cdautomation.com - Web: www.cdautomation.com

Declare that the product / Dichiaro che il prodotto:

CUSTOM 1PH 1100A-1400A-1600A-1800A-2100A

PRODUCT DESCRIPTION: Electric power control

SCOPE OF APPLICATION: Thermal control process

DESCRIZIONE DEL PRODOTTO: Unità di controllo potenza elettrica

UTILIZZO: Controllo processi termici

FULFILLS THE REQUIREMENTS OF THE STANDARD:

Electrical safety Standard	EN60947-1: 2007 + A1 2011, A2 2014
	EN60947-4-3: 2014
Generic Emission standard	EN60947-4-3: 2014 Group 1 Class A emissions
Generic Immunity standard	EN60947-4-3: 2014 Industrial Immunity

SODDISFA I REQUISITI DELLA NORMA:

Specifica di sicurezza	EN60947-1: 2007 + A1 2011, A2 2014
	EN60947-4-3: 2014
Specifica sulle emissioni	EN60947-4-3: 2014 gruppo 1 emissioni classe A
Specifica sulle Immunità	EN60947-4-3: 2014 Immunità industriale

CDAutomation declares that the products above mentioned are conforming to the directive

CDAutomation dichiara che i prodotti sopra menzionati sono conformi alla direttiva

Bassa Tensione (low Voltage) **EMC directive updated 2014/30/EU,**

Low Voltage Directive updated 2014/35/EU

Issued on: 20/03/2017

Data di emissione: 20/03/2017

Amministratore Unico e
Legale Rappresentante

Claudio Brizzi



Important warnings for safety

This chapter contains important information for the safety. The not observance of these instructions may result in serious personal injury or death and can cause serious damages to the Thyristor unit and to the components system included.

The installation should be performed by qualified persons.

In the manual are used symbols to give more evidence at the notes of safety and operativity for the attention for the user:

	This icon is present in all the operational procedures where the Improper operation may result in serious personal injury or death by Electrical Shock Hazard Symbol (a lightning bolt in a triangle) precedes an electric shock hazard CAUTION or WARNING safety statement.
	Warning or Hazard that needs further explanation than the label on unit can provide. Consult User's Guide for further information.
	Unit is compliant with European Union directives. See Declaration of Conformity for further details on Directives and Standards used for Compliance.
	If available, unit is a Listed device per Underwriters Laboratories. It has been investigated to ANSI/UL® 508 standards for Industrial Control Switches and equivalent to CSA C22.2 #14. For more detail search for File E231578 on www.ul.com
	ESD Sensitive product, use proper grounding and handling techniques when installing or servicing product.
	Do not throw in trash, use proper recycling techniques or consult manufacturer for proper disposal.

A “NOTE” marks a short message to alert you to an important detail.

A “CAUTION” safety alert appears with information that is important for protecting your equipment and performance. Be especially careful to read and follow all cautions that apply to your application.

A “WARNING” safety alert appears with information that is important for protecting you, others and equipment from damage. Pay very close attention to all warnings that apply to your application.

Safety notes



WARNING! To avoid damage to property and equipment, injury and loss of life, adhere to applicable electrical codes and standard wiring practices when installing and operating this product. Failure to do so could result in damage, injury and death.



AVERTISSEMENT! Pour éviter d'endommager la propriété et l'équipement, les blessures et la perte de vie, respecter les codes électriques en vigueur et les pratiques de câblage standard au moment de l'installation et de l'utilisation de ce produit. Dans le cas contraire, cela peut entraîner la mort, des blessures graves ou des dommages.

 **WARNING!** All service including inspection, installation, wiring, maintenance, troubleshooting, fuse or other user serviceable component replacement must be performed only by properly qualified personnel. Service personnel must read this manual before proceeding with work. While service is being performed un-qualified personnel should not work on the unit or be allowed in the immediate vicinity.

 **AVERTISSEMENT!** Tous les services, y compris l'inspection, l'installation, le câblage, l'entretien, le dépannage, le remplacement de fusibles ou d'autres composants pouvant être réparés par l'utilisateur, doivent être effectués uniquement par un personnel d'entretien qualifié. Le personnel de service doit lire ce manuel avant d'effectuer tout travail. Pendant que l'entretien est exécuté, tout personnel non qualifié ne doit effectuer de travail sur l'appareil ni se trouver à proximité.

 **WARNING!** When in use the power controller is connected to dangerous voltages. Do not remove the protective covers without first disconnecting and preventing power from being restored while servicing the unit.

 **AVERTISSEMENT!** Au moment de l'utilisation, le régulateur de puissance est connecté à des tensions dangereuses. Ne retirer aucun couvercle de protection sans d'abord débrancher l'appareil et ainsi empêcher l'alimentation d'être rétablie pendant l'entretien.

 **WARNING!** Do not use in aerospace or nuclear applications.

 **AVERTISSEMENT!** Ne pas utiliser pour les applications aérospatiales ou nucléaires.

 **WARNING!** The power controller's protection rating is IP20 with all covers installed and closed. It must be installed in an enclosure that provides all the necessary additional protections appropriate for the environment and application.

 **AVERTISSEMENT!** L'indice de protection du régulateur de puissance est de IP20 lorsque les couvercles sont installés et fermés. L'appareil doit être installé dans une enceinte qui assure toute la protection supplémentaire nécessaire pour l'environnement et l'application.

 **WARNING!** Ground the power controller via the provided protective earth grounding terminal. Verify ground is within impedance specifications. This should be verified periodically.

 **AVERTISSEMENT!** Mise à la terre du régulateur de puissance par le biais de la borne de prise de terre de protection fournie. Vérifier que la prise de terre est conforme aux spécifications de l'impédance. Cela doit être vérifié périodiquement.

 **WARNING!** Electric Shock Hazard: when the power controller has been energized, after shutting off the power, wait at least one minute for internal capacitors to discharge before commencing work that brings you in to contact with power connections or internal components.

 **AVERTISSEMENT!** Risque de décharges électriques: lorsque le régulateur de puissance est mis sous tension, après avoir été éteint, attendre au moins une minute pour que les condensateurs internes se déchargent avant de commencer tout travail incluant le contact avec les connexions électriques ou les composants internes.

 **WARNING!** The installation must be protected by electromagnetic circuit breakers or by fuses. The semiconductor fuses located inside the power controller are classified for UL as supplementary protection for semiconductor devices. They are not approved for branch circuit protection.

 **AVERTISSEMENT!** L'installation doit être protégée par des disjoncteurs électromagnétiques ou des fusibles. Les fusibles pour semi-conducteurs situés à l'intérieur du régulateur de puissance sont classés UL comme protection supplémentaire pour les dispositifs pour semi-conducteurs. Ils ne sont pas approuvés pour la protection des circuits de dérivation.

 **WARNING!** When making live voltage or current measurements, use proper personal protective equipment for the voltages and arc-flash potentials involved.

-  **AVERTISSEMENT!** Au moment de relever des mesures de tension ou de courant en direct, utiliser un équipement de protection individuelle approprié pour les tensions et les potentiels d'arc électrique concernés.
-  **WARNING!** Verify the voltage and current ratings of the power controller are correct for the application.
-  **AVERTISSEMENT!** Vérifier que les valeurs de tension et de courant du régulateur de puissance sont correctes pour l'application.
-  **CAUTION:** To avoid compromising the insulation, do not bend wire or other components beyond their bend radius specifications.
-  **ATTENTION:** Pour éviter de compromettre l'isolation, ne pas plier le fil ou tout autre composant au-delà de ses spécifications en matière de rayon de courbure.
-  **CAUTION:** Protect the power controller from high temperature, humidity and vibrations.
-  **ATTENTION:** Protéger le régulateur de puissance contre les températures élevées, l'humidité et les vibrations.
-  **CAUTION:** The power controller warranty is void if the tested and approved fuses are not used.
-  **ATTENTION:** La garantie du régulateur de puissance est nulle si aucun fusible testé et approuvé n'est utilisé.
-  **CAUTION:** Only trained and authorized personnel should access and handle the internal electronics and they must follow proper electro-static prevention procedures.
-  **ATTENTION:** Seul le personnel formé et autorisé peut accéder aux composants électroniques internes et les gérer, et il doit se conformer à des procédures de prévention électrostatique appropriées.
-  **CAUTION:** Install an appropriately sized RC filter across contactor coils, relays and other inductive loads.
-  **ATTENTION:** Installer un filtre RC de dimensions appropriées sur les bobines du contacteur, les relais et autres charges par induction.
-  **NOTE:** Provide a local disconnect to isolate the power controller for servicing.
-  **REMARQUE:** Fournir une déconnexion locale afin d'isoler le régulateur de puissance pour l'entretien.
-  **NOTE:** The nominal current is specified for ambient temperatures at or below 40° C. Ensure the application design allows for adequate cooling of each power controller. The power controller must be mounted vertically. The cooling design must prevent air heated by one power controller from causing power controllers mounted above to exceed the ambient operating temperature limit. When power controllers are mounted side by side allow a minimum spacing of 15mm between them.
-  **REMARQUE:** Le courant nominal est précisé pour des températures ambiantes égales ou inférieures à 40°C. S'assurer que la conception de l'application permette le refroidissement adéquat de chaque régulateur de puissance. Le régulateur de puissance doit être monté verticalement. La conception de refroidissement doit empêcher l'air chauffé par le régulateur de puissance de dépasser la limite de température de fonctionnement ambiante de la part des régulateurs de puissance montés au-dessus. Lorsque les régulateurs de puissance sont montés côte à côte, il faut conserver un espacement minimal de 15 mm entre les deux.
-  **NOTE:** Use only copper cables and wires rated for use at 75°C or greater.
-  **REMARQUE:** N'utiliser que des câbles et des fils en cuivre pour l'utilisation à 75°C ou plus.



Maintenance

In order to have a corrected cooling, the user must clean the heat-sink and the protective grill of the fans. The frequency of this servicing depends on environmental pollution.

Also check periodically if the screw for the power cables and safety earth are tightened correctly (See Connection Diagram)

Warranty condition

Producer gives a 12 months warranty to its products.

The warranty is limited to repairing and parts substitution in our factory and does exclude products not properly used and fuses.

Warranty does not include products with serial numbers deleted. The faulty product should be shipped to Producer at customer's cost and our Service will evaluate if product is under warranty terms.

Substituted parts remain of Producer property.



Return Material Authorization (RMA)

Customers wishing to return any items, whether they are incorrectly supplied, faulty or damaged in transit, must first complete a Return Material Authorisation (RMA) form to obtain an RMA number from the Service Department.

A full repair service is available for customers. Prior to submitting the RMA form and returning products, customers are recommended to contact the technical support team to determine whether the issue can be resolved with telephone support.

How the RMA service works

The RMA form and details are available on our web sites:

<https://www.cdautomation.com/returns-material-authorisation/>

When completing the RMA form, please be as specific as possible about the problem, including any pertinent application details. The more information given, the more quickly and more thoroughly the problem can be solved. The minimum information required is:

1. The Full Model Number
2. Quantity of units being returned
3. The units Serial Number(s)
4. A description of the problem ("faulty" or "unknown" is not sufficient)



Summary

●	Declaration of conformity	3
●	Important warnings for safety	4
●	Maintenance	7
1	Quick Start	10
2	Basic Connections and sizing	11
3	Identification and Order Code	12
	3.1 Identification of the unit	12
4	Technical Specifications	14
	4.1 General features	14
	4.2 Input features	14
	4.3 Output features 600V	14
	4.4 Output features 690V	14
	4.5 Environmental installation conditions	15
	4.6 Derating Curve and Thermal conditions	15
	4.7 Calculating flow capacity of the fan.	15
5	Installation	16
	5.1 Dimensions and Weight.	16
	5.2 Fixing holes	17
6	Wiring instructions	18
	6.1 Terminals Positions	18
	6.2 Power Terminals	19
	6.3 IP20 Cover OPTION	21
	6.4 Power cable dimensions (suggested)	22
	6.5 Cable dimensions (suggested) of Earth and of the Command Terminals	22
	6.6 Command Terminals	23
	6.7 Fan Supply	25
	6.8 Thermal Switch	25
	6.9 Schematic	26
	6.10 Connection Diagram	27
7	Access to the Electronic Board	28

8	Supply the Electronic Board	29
	8.1 Fuse Board protection	30
9	Control Input type setting.	31
10	Input output signal	32
	10.1 Digital Input.	32
	10.2 Digital Output	32
11	Heater Break alarm and SCR short circuit (HB Option)	34
	11.1 Heater break Calibration procedure	34
	11.2 HB alarm contact	34
12	Control Panel	35
	12.1 Scroll the parameters	37
	12.2 Operator Menu <i>oPEr</i>	38
	12.3 Setup Menu <i>SEt</i>	38
	12.4 Hardware Menu <i>Hw</i>	39
	12.5 Displayed Alarms	40
13	Firing type.	41
	13.1 Zero Crossing (ZC)	41
	13.2 Burst Firing (BF)	41
14	Internal Fuse	42

1

Quick Start



Attention: this procedure must be carried out by skilled people only.

If your Custom HP code is in line with what you really need, then the main configuration is already done by Producer and you just need to do the following steps:

1. Verify Custom HP's current sizing. Be sure that:
 - the load current is equal or less than the nominal one of Custom HP
 - the main voltage is equal or less than the nominal voltage of Custom HP
2. Verify the Installation.
3. Verify the Wiring:
 - all auxiliary connections must be done in line with wirings on this manual
 - verify that there isn't a short circuit on the load
4. Supply the auxiliary voltage of the unit
Give the main voltage supply.
Enable the unit.

Activate the test (calibration) input terminal 2 on M5 to start the tuning load procedure.

The tuning procedure supply 100% of voltage to the load for 10sec and set in automatically mode:

- The load current **A_{Lo}** parameter
- The voltage on load **U_{oP}** parameter
- Set Heater break value setpoint.

This procedure must be done with the real load connected!

The tuning of the load can be done also manually by setting the the parameters

U_{oP} (Operative Voltage) and **P_{Lo}** (Nominal Power of the load) using the frontal keypad.

2

Basic Connections and sizing


Single phase wiring with resistive load

$$I = \frac{P}{V}$$

V = Nominal voltage of the load

I = Nominal current of the load

P = Nominal power of the load




Open Delta wiring with resistive load

$$I = \frac{P}{3V}$$

V = Nominal voltage phase to phase

I = Nominal current to the load

P = Nominal power to the load



3

Identification and Order Code

3.1 Identification of the unit



Caution: Before to install, make sure that the Thyristor unit have not damages. If the product has a fault, please contact the dealer from which you purchased the product.

The identification's label give all the information regarding the factory settings of the Thyristor unit, this label is on the unit, like represented in figure.

Verify that the product is the same thing as ordered.



3.1.1 Order code

	1	2	3	4	5	6		7	8	9	10	11	12	13	14	15	16
CUSTOM 1 Phase	C	1	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CURRENT																	
description																	
1100A																	
1400A																	
1600A																	
1800A																	
2100A																	
MAX VOLTAGE																	
description																	
480V																	
600V																	
690V																	
VOLTAGE SUPPLY AUX																	
description																	
No external power supply internal connection																	
170:265V external voltage supply																	
INPUT																	
description																	
SSR																	
0:10V dc																	
4:20 mA																	
Potentiometer with internal power supply																	
FIRING																	
description																	
Zero Crossing with SSR input																	
Burst Firing configurable from 1 to 255 cycles at 50% power demand																	
CONTROL MODE																	
description																	
Open Loop																	
Voltage feed back																	
Power feed back																	
Current feed back																	
OPTION																	
description																	
None																	
Measurement package including heater break alarm and current, voltage and power read out																	
FAN VOLTAGE																	
description																	
Fan 220V																	
APPROVALS																	
description																	
CE-EMC + IP0 protection standard																	
CE-EMC + IP20 protection (option)																	
MANUAL																	
description																	
None																	
Italian																	
English																	
German																	
French																	
VERSION																	
description																	
Sandard																	

4

Technical Specifications

4.1 General features

Utilization Category	AC-51
IP Code	00 (ip20 on request)
Method of Connecting	Load in Delta, Load in Star
Auxiliary voltage available: (see order code)	90:130V (10 VA Max) 170:265V (10 VA Max) 230:345V (10 VA Max) 300:530V (10 VA Max) 510:690V (10 VA Max)
Relay output alarm:	0.5A a 125VAC

4.2 Input features

Logic input SSR:	4 ÷ 30Vdc 5mA Max (ON ≥ 4Vdc OFF < 1Vdc)
Volt Analogic input	0 ÷ 10Vdc impedance 15 K ohm
Current Analogic input	0 ÷ 20mA impedance 100 ohm 4 ÷ 20mA impedance 100 ohm
POT	10 K ohm min.
Digital Input	4 ÷ 24Vdc 5mA Max (ON ≥ 4Vdc OFF < 1Vdc)

4.3 Output features 600V

Current	Output Voltage range (Ue)	Repetitive peak reverse voltage (Uimp)		Latching current	Max peak one cycle	Leakage current	I ₂ T value max	Frequency range	Power loss
(A)	(V)	(480V)	(600V)	(mA _{eff})	(10msec.) (A)	(mA _{eff})	tp=10msec	(Hz)	I=I _{nom} (W)
1100A	24÷690	1600	1600	700	12500	300	781x1E3	47÷70	1456
1400A	24÷690	1800	1800	700	22400	300	2509x1E3	47÷70	1676
1600A	24÷690	1800	1800	700	22400	300	2509x1E3	47÷70	2169
1800A	24÷690	1600	1600	700	26900	300	3618x1E3	47÷70	2134
2100A	24÷690	1800	1800	700	36000	300	6480x1E3	47÷70	2354

4.4 Output features 690V


Current	Output Voltage range (Ue)	Repetitive peak reverse voltage (Uimp)		Latching current	Max peak one cycle	Leakage current	I ₂ T value max	Frequency range	Power loss	 Number of fans
(A)	(V)	(480V)	(600V)	(mA _{eff})	(10msec.) (A)	(mA _{eff})	tp=10msec	(Hz)	I=I _{nom} (W)	
1100A	24÷690	2200	2200	700	36000	300	6480x1E3	47÷70	1187	One fan 75W
1400A	24÷690	2200	2200	700	36000	300	6480x1E3	47÷70	1612	
1600A	24÷690	2200	2200	700	36000	300	6480x1E3	47÷70	2080	
1800A	24÷690	2200	2200	700	60000	300	6480x1E3	47÷70	2417	

4.5 Environmental installation conditions

Ambient temperature	0-40°C (32-104°F) at nominal current. Over 40°C -104°F use the derating curve.
Storage temperature	-25°C to 70°C -13°F to 158°F
Installation place	Don't install at direct sun light, where there are conductive dust, corrosive gas, vibration or water and also in salty environmental.
Altitude	Up to 1000 meter over sea level. For higher altitude reduce the nominal current of 2% for each 100m over 1000m
Humidity	From 5 to 95% without condense and ice
Pollution Level	Up to 2nd Level ref. IEC 60947-1 6.1.3.2

4.6 Derating Curve and Thermal conditions

The nominal current of the units in specification are referred to continuos service at 40° ambient temperature. For higher temperature multiply the nominal current times derating coefficient K below represented:



4.7 Calculating flow capacity of the fan

All the thyristor units when are in conduction produces power loss that is dissipated inside cubicle in terms of heating. Due to this fact the internal temperature of cubicle is higher than ambient temperature. To be cooled the thyristor need of fresh air cooling and to do it is normally used a fan mounted on the front door or on the roof of the cabinet.

Procedure to size **Fan air mass flow (V)**: see power loss for each thyristor and fuse mounted indicated in the manual related to the current (Output feature and Internal fuse Chapter).

$V=f * \frac{Q_v}{t_c-t_a}$	Qv = total power losses (w) (thyristor + fuse power loss) ta = ambient temperature (°C) tc = cabinet temperature (°C) V = fan air mass flow (m3/h) f = altitude coefficient (see table on right)	Altitude <table><tr><td>0:100 meters</td><td>f = 3.1 m3k/W/h</td></tr><tr><td>100:250 meters</td><td>f = 3.2 m3k/W/h</td></tr><tr><td>250:500 meters</td><td>f = 3.3 m3k/W/h</td></tr><tr><td>500:750 meters</td><td>f = 3.4 m3k/W/h</td></tr></table>	0:100 meters	f = 3.1 m3k/W/h	100:250 meters	f = 3.2 m3k/W/h	250:500 meters	f = 3.3 m3k/W/h	500:750 meters	f = 3.4 m3k/W/h
0:100 meters	f = 3.1 m3k/W/h									
100:250 meters	f = 3.2 m3k/W/h									
250:500 meters	f = 3.3 m3k/W/h									
500:750 meters	f = 3.4 m3k/W/h									



The formulas used are for information only and is not a substitute for a proper thermal rating done by a qualified person.

5


Installation

Before to install, make sure that the Thyristor unit have not damages. If the product has a fault, please contact the dealer from which you purchased the product. Verify that the product is the same thing as ordered.

The Thyristor unit must be always mounted in vertical position to improve air cooling on heat-sink.

Maintain the minimum distances in vertical and in horizontal as represented, this area must be free from obstacle (wire, copper bar, plastic channel).

When more unit has mounted inside the cabinet maintain the air circulation like represented in figure without obstacle for the air flow. Is necessary to install a fan to have better air circulation as calculated previously.



5.1 Dimensions and Weight




1100A-1400A
A: 550mm - Weight: ... Kg



1600A-1800A-2100 A
A: 650mm - Weight: ... Kg

5.2 Fixing holes



1100A
B: 217,5mm

1400A-1600A-1800A-2100A
B: 267,5mm

6


Wiring instructions

The Thyristor unit could be susceptible to interferences lost by near equipments or by the power supply, for this reason in accord to the fundamental practices rules is opportune take some precautions:

- The coil contactor, the relays and other inductive loads must be equipped with opportune RC filter.
- Use shielded bipolar cables for all the input and output signals.
- The signal cables must not be near and parallel to the power cables.
- Local regulations regarding electrical installation should be rigidly observed.

Use copper cables and wires rated for use at 75°C only.

6.1 Terminals Positions





6.2 Power Terminals




Warning: Before connecting or disconnecting the unit check that power and control cables are isolated from voltage sources.

Terminal	Description
L1	Line Input Phase 1
T1	Load Output Phase 1



600V			
1100A-1400A	A: 124mm	B: 54,5mm	C: 140,5mm
1600A-1800A-2100A	A: 125mm	B: 52,5mm	C: 142,5mm
690V			
1100A-1400A	A: 136mm	B: 42,5mm	C: 152,5mm
1600A-1800A-2100A	A: 137mm	B: 40,5mm	C: 154,5mm




1100A	A: 315mm	B: 220mm
1400A-1600A-1800A-2100A	A: 365mm	B: 270mm

6.3 IP20 Cover OPTION


6.3.1 Removing the IP20 cover

For each phase:

- *1 Unscrew the two bottom M6 screws.
- *2 Pull out the bottom cover.
- *3 Unscrew the two upper M6 screws.
- *4 Pull out the upper cover.



6.3.2 IP20 Cover dimension




600V		
1100A	A: 64mm	B: 10mm
1400A-1600A-1800A-2100A	A: 65mm	B: 11mm
690V		
1100A	A: 78mm	B: 10mm
1400A-1600A-1800A-2100A	A: 79mm	B: 11mm

6.4 Power cable dimensions (suggested)

Current	Supply		Load	
	Bar type	Screw M	Bar type	Screw M
1100-1400A	Bus Bar 50x6mm	4xM8	Bus Bar 50x6mm	4xM8
1600-1800A-2100A	Bus Bar 50x8mm	4xM8	Bus Bar 50x8mm	4xM8

6.5 Cable dimensions (suggested) of Earth and of the Command Terminals

Current	Earth			Command Terminals	
	Cable		Screw	Cable	
	mm ²	AWG	M	mm ²	AWG
1100A	95	3/0	M8	0,50	18
1400A	120	4/0	M8	0,50	18
1600A-1800A-2100A	2x95	2x3/0	M8	0,50	18



* Earth connection on left side OR right side

6.6 Command Terminals



Warning: Before connecting or disconnecting the unit check that power and control cables are isolated from voltage sources.

6.6.1 Terminal M5

Terminal	Description
1	Enable Digital Input
2	Test / Configurable Input
3	COM I - Common Digital Input
4	0V GND
5	Output +10Vdc stabilized 20 mA MAX
6	- Control Input (SSR/0-10Vdc/4-20mA)
7	+ Control Input (SSR/0-10Vdc/4-20mA)
8	Output + 24Vdc stabilized 20 mA MAX
9	0V GND
10	Option
11	0V GND

Terminal	Description
12	NC - Normally Close contact alarm relay output (HB in alarm) *
13	C - Common contact alarm relay output (HB) *
14	NO - Normally Open contact alarm relay output (HB in alarm) *
15	NC - Normally Close contact alarm relay output (GENERAL in alarm) *
16	C - Common contact alarm relay output (GENERAL) *
17	NO - Normally Open contact alarm relay output (GENERAL in alarm) *
18	NC - Normally Close contact alarm relay output (FUSE in alarm) *
19	C - Common contact alarm relay output (FUSE) *
20	NO - Normally Open contact alarm relay output (FUSE in alarm) *

* See Digital Output chapter for important details.

6.6.2 Terminal M4


Terminal	Description
1	Aux – Voltage Supply for electronic boards
2	Not Connected
3	Aux – Voltage Supply for electronic boards

6.6.3 Terminal MX

Terminal	Description
1	Fan supply voltage (230V standard - 115V option)
2	Fan supply voltage (230V standard - 115V option)
3	NC - Normally Close contact alarm relay output (HB)
4	PT2 Thermal Switch
5	PT2 Thermal Switch
6	Not connected
7	Not connected
8	Not connected
9	Not connected
10	Not connected
11	Not connected
12	Not connected
13	Not connected
14	Not connected
15	Not connected
16	Not connected


6.7 Fan Supply

Terminal	Description
15	Fan supply voltage (230V standard – 115 option)
16	Fan supply voltage (230V standard – 115 option)



6.8 Thermal Switch


Terminal	Description
13	PT2 Thermal Switch
14	PT2 Thermal Switch



6.9 Schematic



Caution: this procedure must be performed only by qualified persons.




NOTE:

- ***1** The user installation must be protecting by electromagnetic circuit breaker or by fuse isolator. The semiconductor I_{2t} should be 20% less than power controller I_{2t}. Semiconductor fuses are classified for UL as supplemetar protection for semiconductor. They are note approved for branch circuit protection.
- ***2** For the Voltage value see order code (230V-120V)
- ***3** See Digital Output chapter for important details.

Note: with the SSR signal the SSR input (M5 terminal 7,6) must be applied after the enable input

6.10 Connection Diagram



*1 The user installation must be protecting by electromagnetic circuit breaker or by fuse isolator. The semiconductor I_{2t} should be 20% less than power controller I_{2t}.


Semiconductor fuses are classified for UL as supplemental protection for semiconductor.

*2 For the Voltage value see order code (230V-120V).

7

Access to the Electronic Board

Remove the connectors, unscrew the two M6 screws as shown in picture, and pull out the board with the support.



8

Supply the Electronic Board

The Custom HP thyristor unit, to work, requires a voltage supply for the electronic boards.
The Max consumption is 10VA.
The voltage supply for the electronic boards is configured in line with customer requirements that are defined in the Order Code. The Order Code is written on the identification label.



Warning: Before connecting or disconnecting the unit check that power and control cables are isolated from voltage sources.

Terminal	Description
1	Aux – Voltage Supply for electronic boards 230V (120 as option)
2	Not Connected
3	Aux – Voltage Supply for electronic boards 230V (120 as option)


To change auxiliary supply voltage sold the correct link-jumper on board:

Only Link-Jumper JP14+JP6	Only Link-Jumper JP7
115V	230V

If the Auxiliary Voltage (written on the identification label) is different from Supply Voltage (to the load), use an external transformer with primary equal to load voltage and secondary equal to the Auxiliary Voltage.

8.1 Fuse Board protection

The main board is protected with fuses.



9

Control Input type setting


The control input type is already configured in line with customer requirements that are defined in the Order Code. However, verify that the jumper are set as below represented:



Warning: Before operate, be sure that power and control cables are isolated from voltage sources

SSR	SSR Input (see note below)	SW2=B	SW3=B	SW1=B
V	0-10V	SW2=A	SW3=A	SW1=B
I	0-20mA 4-20mA	SW2=A	SW3=A	SW1=A

Note: with the SSR signal the SSR input (M5 terminal 7,8) must be applied after the enable input so before to apply the SSR input signal the unit must be enabled



• Once the input is set with the jumpers set even with the Control Panel

Control input type: *inP* This parameter selects the type of control input. See Control panel chapter

0 = 4-20mA	4 20
1 = 4-20mA	0 20
2 = V	U
3 = SSR	SSr

10

Input output signal

10.1 Digital Input

The Custom thyristor unit has 2 digital inputs opto-isolated to 24Vdc 5 mA.

You can activate the inputs with the internal supply or with an external source for example the PLC.

10.1.1 Configurable Inputs (Terminal 1 -2 of M5)

Both digital inputs are configured by the parameter **Ed 1** and **Ed 2** could perform different functions:

- **None:** no function used **nonE**
- **Enable** (default for input 1): This is the start command (Enable) of the Custom unit.
If you Remove the Start command the Custom thyristor unit will be stopped and the output will return at zero. **EnAb**
Before to apply the SSR input signal the unit must be enabled.
- **Test/Calibration** (default for input 2): when activated the unit drive the load at 100% and stores the Current, Voltage and power value. **CALb**
- **Local Remote:** with this function, when you active the input, the setpoint reference change from Analog input to Digital value in bumpless mode, setted in the parameter **r**. The parameter **r** is not stored in memory. **LcrE**
- not used **rtrU**
- not used **F irn**
- **Reset Alarm:** when you active the input all the alarm are resetted. **ALrS**

10.2 Digital Output

The Custom HP unit is supplied with three relay output on terminal **M5**:

Heater Break – General – Fuse alarm.

- In normal conditions, without alarm and with auxiliary power supply, the relay coil is energized.
- In alarm condition or without auxiliary power supply the relay coil is not energized.

For relay contact status see below.

Terminal	Without Aux Supply	Alarm	No Alarm
HB Relay			
12-13	Closed	Closed	Open
13-14	Open	Open	Closed
General Relay			
15-16	Closed	Closed	Open
16-17	Open	Open	Closed
Fuse Relay			
18-19	Closed	Closed	Open
19-20	Open	Open	Closed

10.2.1 Configurable Outputs (Terminal 12 -13-14 and 15-16-17 of M5):

Two digital outputs are configured by the parameter **do1** (HB Relay as default, terminal 12-13-14) and **do2** (General, terminal 15-16-17) could perform different functions:

- **None:** no function used **nonE**
- **Enable:** when one of the input is in Enable mode the relay change status. **EnAb**
- not used **noAL**
- not used **SPH**
- **Phase loss:** when the voltage in one phase is zero the relay changes status. **noPH**
- **Fuse Fault:** when a fuse blow the relay changes status. **FUSE**
- **Fan Fault:** when one fan stop to work the relay changes status. **AnEn**
- **Thermal Switch:** when the temperature of heatsink cross the limit value the relay changes status. **tHER**
- **Heater Break alarm:** when the HB alarm is active of heatsink the relay changes status. **Hb**
- **Short Circuit:** when a short circuit on thyristor is detected the relay changes status. **SHrt**
- **Any alarm:** any type of alarm changes status of relay. **AnY**

11

Heater Break alarm and SCR short circuit (HB Option)



Caution: to work properly the load must be powered at least about 160msec.

The Heater Break circuit read the load resistance with an Internal voltage transducer and Internal current transformer (C.T.), to calculate the resistance (V/I).

Minimum current is 10% of the current transformer size.

If load current is below this value the Heater Break Alarm doesn't work properly.

11.1 Heater break Calibration procedure

An automatic function sets the Heater Break Alarm, when one of the configurable input is in **CALb** mode and input is on.

Digital input 2 is in calibration mode as default.

If the load resistance increases due to a partial or total load failure, the HB alarm become ON and alarm relay change status.

When the alarm condition disappear the alarm is resetted automatically.

You can Adjust the sensibility of HB alarm by using the parameter **Hb_S**. This parameter is set between 1 and 255% of the nominal resistance.

This parameter is the maximum increment of the resistance Load to establish the HB Alarm.

There is also **Hb_d** parameter to set a delay to have HB alarm active.


11.2 HB alarm contact

The Revo unit with HB option, is supplied with Heater Break alarm on terminal 12-13-14 of M5:

Terminal	Without Aux Supply	Alarm	No Alarm
HB Relay			
12-13	Closed	Closed	Open
13-14	Open	Open	Closed

12 Control Panel

The Control Panel is placed on the front of the thyristor unit, on his display you can visualize the alarms, the input and output signals and all the configuration parameters.




The function keys are the following:

- The **Function key** **F** is used to scroll the parameter V Po Anp.
- The **UP key**  and **DOWN key**  are used to set the parameters in the menu and to change data.
- The **L/R key** is used to edit the parameters and to save the modified values.
- The **F** + **L/R** is used for enter and exit from the menu.


The Control Panel have three menu, and to enter in one of them you must set correctly the parameter *PASS*.

- **Operator Menu (*PASS* = 2)**
This menu contains a reading parameters that give information on the state of the unit, it include also the base parameters for quick start, like the value of current and voltage load and the Set-point data.
- **Hardware Menu (*PASS* = 5)**
This menu contains all the configuration parameters for analogic and digital I/O, and the parameters to set the serial port like the address and the baudrate.
- **Setup Menu (*PASS* = 10)**
This menu contains all the setting parameters to configure the thyristor unit, like the firing type, the current limit, etc.




12.1 Scroll the parameters


Operator Menu *oPEr*



Setup Menu *SEt*



Hardware Menu *Hw*



12.2 Operator Menu αPEr

- Push simultaneously **L/R** and **F** for few seconds to access to the menu ($nEnu$ flashing).
- Select by arrows **UP** and **DOWN**: αPEr then press **F**.
- Select by arrows **UP** and **DOWN**: 2 as password then press **F**.
- You have access to the parameter on αPEr menu.
- Select by arrows **UP** and **DOWN** the required parameter.
- If the parameter is **Write/Read (W/R)** press **F** (parameter flashing) then select by arrows **UP** and **DOWN** the required value, press **F** to set the new value.
- Push **L/R** to Exit from the menu
- **Ramp up:** $r Pu$ Is the settable time to reach the full thyristor conduction (100% output)
- **Ramp Down:** $r Pd$ Is the settable time to reach the zero thyristor conduction (0% output)
- **Read Power output:** Po This parameter shows the Average power output.
- **Current Value Phase R:** Ir This parameter shows the instant value current output on phase R.
- **Current Value Phase S:** Is This parameter shows the instant value current output on phase S.
- **Current Value Phase T:** It This parameter shows the instant value current output on phase T.
- **Set Load Voltage:** $U \alpha P$ This parameter is used to set in Volt the operative voltage of the load.
- **Load nominal Power:** $P Lo$ This parameter is used to set in kWatt the nominal power of the load.
- **Load nominal Current:** $A Lo$ This parameter shows the current on the load.

12.3 Setup Menu SEt

- Push simultaneously **L/R** and **F** for few seconds to access to the menu ($nEnu$ flashing).
- Select by arrows **UP** and **DOWN**: SEt then press **F**.
- Select by arrows **UP** and **DOWN**: 10 as password then press **F**.
- You have access to the parameter on SEt menu.
- Select by arrows **UP** and **DOWN** the required parameter.
- If the parameter is **Write/Read (W/R)** press **F** (parameter flashing) then select by arrows **UP** and **DOWN** the required value, press **F** to set the new value.
- Push **L/R** to Exit from the menu
- **Phase rotation Algorithm:** rot This parameter enable or disable the phase rotation algorithm used to optimize and reduce the noise (only in burst firing)

Sample Values and Note

nor	Disabled
rot	Enabled

- **Burst Firing Cycles number:** bFn It defines the number of voltage cycles in ON condition at 50% of power demand.
- **Firmware version:** $UErS$ This parameter shows the firmware version number.

12.4 Hardware Menu *Hu*

- Push simultaneously **L/R** and **F** for few seconds to access to the menu (*Menu* flashing).
- Select by arrows **UP** and **DOWN**: *Hu* then press **F**.
- Select by arrows **UP** and **DOWN**: *5* as password then press **F**.
- You have access to the parameter on *Hu* menu.
- Select by arrows **UP** and **DOWN** the required parameter.
- If the parameter is **Write/Read (W/R)** press **F** (parameter flashing) then select by arrows **UP** and **DOWN** the required value, press **F** to set the new value.
- Push **L/R** to Exit from the menu
- **Digital input 1 configuration:** *cd 1* This parameter selects the function of digital input 1 Terminal

Sample Values and Note	
None	<i>nonE</i>
Enable the unit	<i>EnAb</i>
Calibration	<i>CALb</i>
Local Remote	<i>LcrE</i>
Feedback Selection	<i>rtrU</i>
Change Firing type	<i>Firn</i>
Reset Alarm	<i>ALrS</i>

- **Digital input 2 configuration:** *cd 2* This parameter selects the function of digital input 2.

Sample Values and Note	
None	<i>nonE</i>
Enable the unit	<i>EnAb</i>
Calibration	<i>CALb</i>
Local Remote	<i>LcrE</i>
(not used)	<i>rtrU</i>
(not used)	<i>Firn</i>
Reset Alarm	<i>ALrS</i>

- **Set HB sensitivity:** *Hb 5*
This parameter defines the threshold of resistance that activates the HB alarm
This value is in percentage respect the nominal resistance load value
- **Control input type:** *InP* This parameter selects the type of control input.

0 = 4-20mA	<i>4 20</i>
1 = 4-20mA	<i>0 20</i>
2 = V	<i>U</i>
3 = SSr	<i>SSr</i>

- **Digital Output 1 configuration:** *do1* This parameter selects the function of digital output1

Sample Values and Note			
None	<i>nonE</i>	Fan Fault	<i>AnEn</i>
Enable	<i>EnAb</i>	Thermal Switch	<i>tHEr</i>
(not used)	<i>noAL</i>	Heater Break alarm	<i>Hb</i>
(not used)	<i>SPH</i>	Short Circuit	<i>SHrE</i>
Phase loss	<i>noPH</i>	Any alarm	<i>AnY</i>
Fuse Fault	<i>FUSE</i>		

- **Digital Output 2 configuration:** *do2* This parameter selects the function of digital input2

Sample Values and Note			
None	<i>nonE</i>	Fan Fault	<i>AnEn</i>
Enable	<i>EnAb</i>	Thermal Switch	<i>tHEr</i>
(not used)	<i>noAL</i>	Heater Break alarm	<i>Hb</i>
(not used)	<i>SPH</i>	Short Circuit	<i>SHrE</i>
Phase loss	<i>noPH</i>	Any alarm	<i>AnY</i>
Fuse Fault	<i>FUSE</i>		

12.5 Displayed Alarms

Alarm on Display	Description
<i>Hb r</i>	Heater Break Alarm phase R!
<i>Hb S</i>	Heater Break Alarm phase S!
<i>Hb t</i>	Heater Break Alarm phase T!
<i>PHAS</i>	Phase loss!
<i>FAn</i>	Fan Fault!
<i>FUSE</i>	Fuse Fault!
<i>tHS</i>	Thermal Switch!
<i>Sc r</i>	Short Circuit on SCR Phase R!
<i>Sc S</i>	Short Circuit on SCR Phase S!
<i>Sc t</i>	Short Circuit on SCR Phase T!

13

Firing type

Choose a correct firing type allows to optimize the thyristor unit for the installed load.

The firing type has already configured in line with customer requirements, Zero Crossing for SSR input and Burst firing for Analog Input.




Caution: this procedure must be performed only by qualified persons.

13.1 Zero Crossing (ZC)

ZC firing mode is used with Logic Output from temperature controllers and the Thyristor operates like a contactor.

The Cycle time is performed by temperature controller. ZC minimizes interferences because the Thyristor unit switches ON-OFF at zero voltage.




13.2 Burst Firing (BF)

The Burst Firing is similar to the Single Cycle, but consecutive cycles ON are selectable between 2 and 255, with input signal equal at 50%.

Burst Firing is a method zero crossing that it reduces the electromagnetic interferences because the thyristor switches at zero voltage crossing.

The example show the Burst Firing with Burst cycles: 4



14

Internal Fuse

The thyristor unit have internal fuse extrarapid at low I^2t for the thyristor protection of against the short-circuits. The Fuses must have I^2t 20% less than thyristor's I^2t . The warranty of thyristor is null if no proper fuses are used.

Remove cover, remove screws and fuses.

TORQUE for M12 fuse screws min: 32 Nm to Max: 52 Nm

600V

Thyristor Size	Fuse CODE	200 kARMS Symmetrical A.I.C.				Qty for each Phase
		Current (A RMS)	Power Loss (W)	FUSE I^2t value Suggested A2s (at 660V)*	Vac	
1100A	FU800SIB SQB3 690-700V	800	118	480.000	690	2
1400A	FU1250A SQB3 690-700V	1100	136	1.200.000	690	2
1600A	FU1400SIB SQB3 690-700V	1250	147	1.750.000	690	2
1800A	FU1400SIB SQB3 690-700V	1400	161	2.200.000	690	2
2100A	FU1600SIB SQB3 600V	1600	190	3.700.000	690	2

690V

Thyristor Size	Fuse CODE	200 kARMS Symmetrical A.I.C.				Qty for each Phase
		Current (A RMS)	Power Loss (W)	FUSE I^2t value Suggested A2s (at 1000V)*	Vac	
1100A	FU1000SIB SQB3 1000V	1000	150	1.900.000	1000	2
1400A	FU1250SIB SQB3 900V	1250	198	3.300.000	1000	2
1600A	FU1400SIB SQB3 900V	1250	210	3.900.000	1000	2
1800A	FU1400SIB SQB3 900V	1400	210	3.900.000	1000	2



Caution: High speed fuses are used only for the thyristor protection and can not be used to protect the installation.



Caution: The warranty of thyristor is null if no proper fuses are used. See tab.



Warning: When it is supply, the Thyristor unit is subject to dangerous voltage, don't open the Fuse-holder module and don't touch the electric equipments.



CD Automation S.r.l.

Via Picasso, 34/36 - 20025 Legnano (MI)- Italy

Tel. +39 0331 577479 - Fax +39 0331 579479

E-mail: info@cdautomation.com - Web: www.cdautomation.com