



GENERAL DESCRIPTION

- This unit is available in three version as in drawing on next pages
- Each unit includes Fuse and Fuse Holder, thyristor and heat sink with its own Firing circuit
- Zero Crossing Firing
- Insulated input
- LED for On Off Status indication
- LED for fuse failure indication
- Plug in connection for auxiliary and power terminations
- Small dimensions Width: 36 Depth: 86 Height:121
- Din rail mounting or screw mounting
- Can be used in applications with many zones and low power as thermoforming, blow Moulding and Hot Runners
- Total load failure alarm is available as standard on 480V version

TECHNICAL SPECIFICATION

GENERAL FEATURES

Cover and Socket material	PolymericV2
Mounting	DIN bar (thickness type 1mm Max)
Nominal voltage range Ue:	24 ÷ 480V
Delay switch ON time	0,5 period Max
Delay switch OFF time	0,5 period Max

INPUT FEATURES

Logic imput SSR	4 ÷ 30Vdc 5mA Max (ON ≥ aVdc OFF < 1Vdc)
Firing	Zero Crossing or Random
Mounting	Side by side mounting
Operating Temperature	40°C without derating. Over this temperature see below derating curve
Storage Temperature	-25 °C to 70 °C Max
Altitude	over 1000m of altitude reduce the nominal current of 2% for each 100m
Humidity	from 5 to 95% without condense and ice



OPTION'S FEATURES AND SPECIAL DETAILS

TOTAL LOAD FAILURE ALARM OR SHORT CIRCUIT ON THYRISTOR

The alarm circuit checks if the load is connected to the unit and the health state of the semiconductor used for switching (SCR short circuit).

The alarm is active only when the unit is in OFF status. This unit don't need calibration.



The diagnostic circuit also checks the fuse, if the fuse is interrupted a red Led is ON showing the blown fuse, also in this case the relay switching contact HB is active.

The alarm is stored, to reset the alarm you have to remove the auxiliary power supply (terminals 11 -12).

Total Load Failure Alarm Contact

The Revo unit with this option, is supplied with Total Load Failure Alarm Contact normally opened (NO):

- In normal conditions (without alarm) and with auxiliary power supply, the contact to the terminals has opened.
- In alarm condition the contact to the terminals is closed (relay coil energized).
- On request is possible to have the alarm contact normally closed (NC).

HOW TO ADD POWER LOAD MANAGMENT AND FEATURES TO YOUR SIMPLE UNITS



480V with HB

RED

Off

Off Off

Off

FUS 🚺 HB

Off All OK

ON

ON Fuse Fa

GREEN

O ON

Off ON Off ON Off

APPLICATION WITH 8, 16 OR 24 SINGLE PHASE LOADS



WITHOUT POWER CONTROL OPTI-MISATION



WITH POWER CONTROL OPTIMISA-TION Use REVO-PC and you can add these Features

- Communication with different field bus
- Reading of current Voltage and Power
- Istantaneus power very close to average value, no pick power
- Power factor close to one no harmonics
- Prevents increase in energy supply tariffs imposed by your electricity supplier

Synchronization

On all controlled zones, REVO-PC Synchronization is automatic resulting in superior performance:

- Total current is equal to a sinusoidal wave form.
- Power factor > 0,9.
- Instantaneous current close to average value.
- Cancellation of harmonics.
- Flickering effect removed.

Smart power limitation

- Smart power limitation works together with synchronization. If this function is enabled, REVO-PC makes a live calculation of power at each period and generates the output values for the next period. If the calculated power is below the power limit value, the previous values remain with each channel using full power.
- If the power is above the power limit value, the setpoint of each channel is reduced proportionally to restrict power overshoot. This function significantly reduces disturbances on the main network compared to a full power system, preventing any increase in energy tariffs imposed by the electricity supplier.
- This function can be activated/deactivated and the limit value changed at any time.

APPLICATIONS AND FOCUS ON:

- Chiller application.
- Infrared lamp.
- Autoclaves.Fournaces.
- Thermoforming
- Extrusion line.
- Dryers
- Climatic chambers
- Chemical
- Pharmaceutical

WIRING CONNECTION REVO SX 230V





3 OFF Channels 4,5A each

- 3 OFF Fuse and Fuse Holder
- 3 OFF Solid State Relays
- 3 OFF Input Signal
- Indication Fuse Failure
- Indication ON-OFF status
- Internal Heat Sink



WIRING CONNECTION REVO SX 480V Total Load Failure Alarm or Short Circuit on Thyristor Diagram of control connection 4x3,5A 480V LI 1.1 N N LOAD 4 OFF Channels 3,5A each 4 OFF Fuse and Fuse Holder 10 0 15 14 9 13 Z3 Z4 Z1 Z2 4 OFF Solid State Relays ** ** ** ** 4 OFF Input Signal h 1 Indication Fuse Failure Indication ON-OFF status Indication of total load failure Input: AUX 12-24 AC/DC Internal Heat Sink SSR Z1 HB ALARH Relay OUT SSR ZZ SSR Z3 SSR Z4 Diagram of control connection 3x4,5A 480V ù, 1.1 N LOAD

13

Input:

SSR Z1

SSR ZZ

0

** **

Z3

Z1 Z2

19

AUX 12-24 AC/DC

HB ALARM Relay OUT

20

3 OFF Channels 4,5A each 3 OFF Fuse and Fuse Holder

3 OFF Solid State Relays

Indication Fuse Failure
Indication ON-OFF status
Indication of total load failure

3 OFF Input Signal

Internal Heat Sink



POWER OUTPUT FEATURES							
Nominal current in continuos service:	4x3,5A - 3x4,5A - 2x7A						
Voltage range:	24 ÷ 480V						
Repetitive peak reverse voltage Uimp	1200 (480V)						
Latching current:	250mA						
Max peak one cycle (10ms):	230A						
Leakage current:	15mA eff						
I ² T Thyristor value tp=10msec:	610 A ² S						
Frequency range:	47 ÷ 70Hz						
Power loss (I=Inom):	4x4,2W - 3x5,4W - 2x8,4W						
Isolation Voltage Ui:	2500Vac						

DIMENSION AND FIXING HOLES



		1	2	3	4	5	6		7	8	9	10	11	12	13	14	15	16		
REVO - SX		R	S	X	_	_	_	-	_	_	_	_	_	_	_	_	_	_		
4,5,6 Number of Zones		9	9 Input					12	Fu	se and	Optio	ons		15		Manu	nuals			
x Current	x Current Rating		Description code			Numeric	Description code Numeric				eric cod	e	Descri	iption co	de	Numeric code				
Description code	Numeric code		S	SR		S		Fuse a	nd Fuse		F		None			0				
4 Zones 3,5A each	403							Total Load Failure with				1 (1)		Italian Manual			1			
3 Zones 4,5A each	304	1	0		Firing				latchin	g		L (I)		English Manual			2			
2 Zones 7A each	207		Description code			Numeric	code	17				German Manual			3					
7 Main Supply Voltage			Zero Crossing			Z		13	is Fan Voltage					French Manual			4			
		R	amdom	(used w	vith			Description code			Nun	neric cod	e							
Description code	Numeric code		REVO-PC)			R		No fan Voltage				0		16 Vers			on			
230V	2							14						Description code				c code		
480V	4 <mark>(2)</mark>	1	11 Control			ode		14 Appro			ovais			Version 1			1			
			Description code Numerio				code	Description code			Nun	neric cod	le							
8 Auxiliary	voitage		Open Loop			0		CE EMC For European			1									
Description code	Numeric code	L							Marke	et		0								
No Auxiliary Voltage with 230V	0																			

4

Note (1):This option is available only on 480V version Note (2):The 480V version have the dimensions: Widht: 48 Height: 121 Depth: 86 mm



12-24V ac-dc with 480V